


ACROW IMP



*Caution: Excessive tightening torque will damage the chuck, nut or / and collet permanently!

Part No.	Ød Range	ØD	L	Nut	Collets	Wrench
HSK40A-ER10-080	Ø0.5 ~ Ø10.0	28	80	ER16	ER16	W-ER16
-ER20-080	Ø1.0 ~ Ø13.0	34		ER20	ER20	W-ER20
-ER25-080	Ø1.0 ~ Ø16.0	42		ER25	ER25	W-ER25
-ER32-080	Ø1.5 ~ Ø20.0	50		ER32	ER32	W-ER32

HSK50A-ER16-100	Ø0.5 ~ Ø10.0	28	100	ER16	ER16	W-ER16
-ER20-100	Ø1.0 ~ Ø13.0	34		ER20	ER20	W-ER20
-ER25-100	Ø1.0 ~ Ø16.0	42		ER25	ER25	W-ER25
-ER32-080	Ø1.5 ~ Ø20.0	50	80	ER32	ER32	W-ER32
-100			100			

HSK63A-ER16-100	Ø0.5 ~ Ø10.0	28	100	ER16	ER16	W-ER16
-160			160			
-ER20-100	Ø1.0 ~ Ø13.0	34	100	ER20	ER20	W-ER20
-160			160			
-ER25-100	Ø1.0 ~ Ø16.0	42	100	ER25	ER25	W-ER25
-ER32-080	Ø1.5 ~ Ø20.0	50	80	ER32	ER32	W-ER32
-100			100			
-ER40-120	Ø3.0 ~ Ø26.0	63	120	ER40	ER40	W-ER40